

**Oscilloscope Option SSD
Solid State Drive
Installation**

www.tektronix.com



071-2851-01

Tektronix

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

Contacting Tektronix

Tektronix, Inc.
14150 SW Karl Braun Drive
P.O. Box 500
Beaverton, OR 97077
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit www.tektronix.com to find contacts in your area.

Solid State Drive Option

This option provides a solid state drive for the following instrument series:

- DPO5000, MSO5000
- DPO7000C
- DPO70000C, DSA70000C, MSO70000C

Instrument features are the same with the solid state drive as with the standard drive. The solid state drive is faster and more rugged than a standard drive.

For a list of available options, see the Tektronix Web site (www.tektronix.com) or your Tektronix representative.

Installation Instructions

These instructions are for qualified service personnel who are familiar with servicing the product. If you need further details for disassembling or reassembling the product, refer to the appropriate product manual. Contact your nearest Tektronix, Inc., Service Center or Tektronix Factory Service for installation assistance.

Wear a properly grounded antistatic strap and use antistatic handling procedures when removing, installing, and handling the hard drives.

Removal and Installation

Refer to the graphic when using the following procedure:

1. Power off the instrument.
2. For DPO/MSO5000 instruments, remove the drive cover.
3. Loosen the thumb screw(s) and remove the hard drive as shown.
4. Install the solid state drive as shown, and then tighten the thumb screws to secure the drive in the instrument.
5. For DPO/MSO5000 instruments, install the drive cover.

